

FANATEC BMW & PORSCHE WHEEL SNAP ACTION SHIFTER ADDON

AUGUST 2017



This simple add on to the BMW and Porsche wheels will add amagnetic snap action to your wheel and enhance the feel of shifting.

Very simple to fit and totally reversable.

For this guide we have used the BMW wheel, but the instructions are the same for the Porsche.

Fitting instructions:

In the box you will have a pair of plates in either acrylic or carbon fibre. Magnets should be attached.



You will also have 4x M3 10mm long screws and a pair or magnets to attach to the Fanatec paddle.



You will need the following tools...



1. Cross head screwdriver
2. 2mm Hex key
3. 2.5mm Hex key

IMPORTANT NOTE

Before we start a note about magnets. The magnets we use are very powerful and will join together at quite a force. They are also very brittle and if you allow them to snap together they will BREAK! So be careful and handle them with great care. If you do get them stuck to each other slide them apart as you will not be able to just pull them apart, they are too strong.

STEP 1

Turn your wheel over so that the quick release is in front of you.



Locate the cross head screws by the shifter. There are two screws per shifter. Remove them both and put aside. You will not need these again unless you wish to remove the add on kit at a later date.



STEP 2

Take one of the kit plates (sorry for the photo without the magnet, yours will have a magnet attached) and using the supplied longer bolts attach it to the wheel into the holes left after removing the cross head screws. Use the 2mm hex key to tighten the bolts. They do not need to be too tight otherwise you may damage the wheel plastic back cover.



STEP 3

The final step is to add a second magnet to the underside of the paddle. The magnets are supplied with double sided tape this is needed to stop the magnet moving about.

Optional...

To ensure a good final fit and snap it is preferable to have the paddle rest against the add on plate. The left picture is bad and the right one good.

To make a good fit, before adding the second magnet just loosen the bolts holding the paddle slightly and push the paddle so it is resting on the add on plate.



Take the magnet in your hand with the sticky side up and introduce it gently to the paddle allowing it to find it's own position. It will be drawn into place by the other magnet.



Finally, if you loosened the paddle bolts, tighten them up.

Repeat on the other side of the wheel and you should end up with your wheel looking like this.

