

SIMuCUBE 2 QR Fitting Instructions for SRM Conversions

What you get in the QR pack

1. Pack of bolts
2. Star shaped plate
3. Spacer
4. QR part

You will need all of these parts to fit the QR to one of our conversion kits or a converted wheel.

The QR will fit using 6 M5 bolts.

You will need a 4mm Hex Key (not included)



1. Start with your wheel... This guide uses a Fanatec Porsche wheel.



2. Place the star shaped part onto the conversion exactly as shown. It is important that the holes are in the position shown. Attach the Star shaped part using the 6 x medium length (16mm) bolts. You can just hand tighten these for now and finish them last.



3. Using the 4 long bolts attach washers and slide them into the spacer as shown. Make sure the 4 threaded holes are as shown. Make sure these bolts are tight.



4. Finally using the 4 short bolts and washers attach the grooved QR part as shown. Tighten the bolts to finish.

